

KENWOOD

M-819DAB: FIRMWARE UPDATE

Verbesserungen: Funktion der CD-Schublade optimiert.

Vorbemerkung: Netzstecker muss zugänglich sein!

Die Spannungsversorgung darf während des Updates nicht unterbrochen werden!

(DE) Vorgehensweise:

1. Dateien auf einen leeren USB-Stick in das oberste Verzeichnis entpacken (boot.ali und nemo.bin).
2. M-819DAB einschalten und Quelle „USB“ wählen.
3. USB-Stick einstecken.
4. Im Display erscheint „UPGRADE“ und es werden 5 Pieptöne wiedergegeben.
5. Nach ca. 30 Sekunden ist das Update abgeschlossen und es werden wieder Pieptöne ausgegeben.
6. Dann direkt den Netzstecker ziehen und nach ca. 20 Sekunden wieder einstecken.

Improvement: CD tray function optimized.

Preliminary Remarks: Power cord must be reachable!

The power supply must not be interrupted during the update!

(ENG) Procedure:

1. Unzip the files to an empty USB stick on the Root directory (boot.ali and nemo.bin).
2. Switch on M-819DAB and select source „USB“.
3. Insert the USB stick.
4. The display will show „UPGRADE“ and 5 beeps will sound.
5. After about 30 seconds, the update is complete and you will hear again beeps.
6. Then unplug directly the mains connector and plug in again after approx. 20 seconds.