

KENWOOD

M-918DAB: FIRMWARE UPDATE

Verbesserungen: Bass und Treble Einstellung geht zurück auf „0“, wenn die Lautstärke verändert wird.

Vorbemerkung: Netzstecker muss zugänglich sein!

Die Spannungsversorgung darf während des Updates nicht unterbrochen werden!

(DE) Vorgehensweise:

1. Dateien auf einen leeren USB-Stick entpacken (boot.ali und nemo.bin).
2. M-918DAB einschalten und Quelle „USB“ wählen.
3. USB-Stick einstecken.
4. Im Display erscheint „UPGRADE“ und es werden 5 Pieptöne wiedergegeben.
5. Nach ca. 30 Sekunden ist das Update abgeschlossen und es werden wieder Pieptöne ausgegeben.
6. Dann direkt den Netzstecker ziehen und nach ca. 20 Sekunden wieder einstecken.

Improvement: Bass and Treble switched back to „0“, if the volume level will be changed.

Preliminary Remarks: Power cord must be reachable!

The power supply must not be interrupted during the update!

(ENG) Procedure:

1. Unzip the files to an empty USB stick on the Root directory (boot.ali and nemo.bin)
2. Switch on M-918DAB and select source „USB“
3. Insert the USB stick
4. The display will show „UPGRADE“ and 5 beeps will sound
5. After about 30 seconds, the update is complete and you will hear again beeps
6. Then unplug directly the 220V connector and plug in again after approx. 20 seconds