KENWOOD

Installation Manual Double DIN Kit

Part-No.: CAW 2143-15

• Hyundai Santa Fe 2008->

Compatible with these Kenwood double DIN devices

Kenwood Navigation



- Double DIN KIT contents
- (1) Mounting Bracket (L)
- (2) Mounting Bracket (R)
- (2) Facia Plate
- (4) Fixing Screws

All installation work must be performed by a qualified professional installer only. The manufacturer / dealer is not liable for any kind of incidential or indirect damages.

© 07/2009 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

Installation Manual Double DIN Kit CAW 2143-15

2.



1. Hyundai Santa Fe dashboard



5. Place the Kenwood Navigation with the facia plate at the dash board

Connect all required circuit points

Fix the facia plate to the dashboard with four screws

6. Place the OEM front panel

Reinstall everything in reverse order to finish installation.





3. Unclip the center panel and remove it

Remove the screws,

holding the center panel



4. Attach the mounting brackets to the facia plate

Push the Kenwood Navigation into the facia plate and fix it with screws at both sides

All installation work must be performed by a qualified professional installer only. The manufacturer / dealer is not liable for any kind of incidential or indirect damages.