


Installation Manual Double DIN Kit

Standard: CAW 2340-03 Rubber-Touch: CAW 2340-03-RT

• Škoda Octavia II 2004 →

Compatible with these Kenwood double DIN devices

Kenwood Navigation



Double DIN Set contents

- (1) Metal Frame
- (2) Installation Kit

- (3) Facia Plate / Mounting frame
- (4) Trim Frame

Installation Manual Double DIN Kit CAW 2340-03 / CAW 2340-03-RT



1. Remove dashboard panel.



 Remove 4 screws fixing the OEM head unit.
Remove OEM head unit.



 Place mounting frame on the dash board and fix it with the original screws.

Push the metal frame into the mounting frame.



(sample)

Mount the metal brackets with the double DIN head unit



(sample)

The position of the copper coloured holder can be adjusted to your needs for perfect fit. (see sample)

4. Connect all required circuit points and push the double DIN head unit in the metal frame until it snaps in.

Place the facia plate on the dashboard.

Place the trim frame. Reinstall everything in reverse order to finish installation.



All installation work must be performed by a qualified professional installer only. The manufacturer / dealer is not liable for any kind of incidential or indirect damages.